



MOUNTING

Once you have completed the assembly steps and the light bars are attached to the SPYDR Series console, turn fixture over on a clean surface to prepare for mounting. Ensure structure can support weight of SPYDRx (22 lbs) or SPYDRx PLUS (32 lbs).



C-BRACKET CLOSE MOUNTING



unnecessary pressure.

HOW TO APPLY YOUR VINYL-CUT FLUENCE STICKER

- 1 Clean and dry the surface where the sticker will be applied.
- 2 Remove backing sheet to expose adhesive and apply sticker to desired surface.
- 3 Starting from the center and working outward, squeegee pre-masked surface with a credit card to remove air bubbles.
- 4 Allow adhesive to bond approximately 15 minutes before removing the back of the sticker at a 45° angle, keeping it as close to the sticker as possible. If lettering is coming up with back, re-squeegee before attempting to remove.



Last, and most important, please recycle all packaging material.

Future generations will thank you.



Review our products, share your grow and stay abreast of the latest Fluence news and product releases through the channels below:

ff **y o** 8+ in

512.212.4544 • fluence.science